



DataHub 1000 User Manual

## Contents

1 Safety	
2 Overview of DataHub	2
2.1 Introduction	
2.2 Appearance	2
2.3 LED Indicator	2
3 Installation	4
3.1 Packing List	4
3.2 Device Installation	4
3.2.1 Indoor Wall Mounting	4
3.2.2 Guide Rail Mounting	
4 Cascade Connection	
4.1 Inverter Connection	
4.2 Installation of RS485	
4.3 Installation of DI Signal Cable	7
4.4 Installation of AI Signal Cable	7
4.5 Installation of DO Signal Cable	
4.6 Installation of Network Cable	
4.7 Connecting to Ripple Control Receiver	9
4.8 Connecting to DRED	9
5 Configuration Function	
5.1 Login	
5.2 Site Management	
5.2.1 Add Device	
5.2.2 Device Detail	
5.3 Sits Setting	
5.3.1 Export Limit Control	
5.3.2 Power Control	
5.3.3 Meter Reversion	14
5.4 Inverter Setting	14
5.4.1 Inverter Active/Reactive Power Setting	14
5.4.2 Remote System Switch	14
5.4.3 Parameter Setting	
5.5 Inverter Upgrade	
5.6 DataHub Setting	



5.6.1 Internet Setting
5.6.2 Time Setting
5.6.3 Serial Port Settings
5.6.4 Other Setting
5.6.5 Datahub Information17
5.6.6 DataHub Upgrade
5.7 Password Modification 17
5.8 System Resetting
6 Technical Specifications
7 Certified Quality Assurance
7.1 Certification mark
7.2 Warranty
7.3 Warranty Conditions
7.4 Exclusion of Liability
8 Contact Us



## 1 Safety

The DataHub produced by SolaX Power Network Technology (Zhejiang) Co., Ltd. has been designed and tested strictly in accordance with relevant safety regulations. The safety instructions must be followed when installing and maintaining the electrical and electronic equipment. Improper operation will cause personal injury and property damage to the operator and the third party.

- > Children should be supervised to ensure that they do not play with DataHub;
- Please do not open the top cover. Touching or replacing the components without authorization of SolaX may cause personal injury or DataHub damage. SolaX does not assume any responsibility and warranty; and
- Static electricity may damage the electronic components; therefore, appropriate anti-static measures should be taken.



## **2 Overview of DataHub**

## 2.1 Introduction

DataHub, a special equipment of the monitoring platform of photovoltaic power generation system, has realized many functions, with details as follows: interface aggregation, data acquisition, data storage, output control, and centralized monitoring and centralized maintenance of inverters, electricity meters, environmental monitors and other equipment in photovoltaic power generation systems.

### 2.2 Appearance



### 2.3 LED Indicator

Sign	Status	Explanation
RUN	Flash	The program runs normally.
(GREEN)	No Flash	The program runs abnormally.
SERVE	ON	The network connection is normal.



#### DataHub 1000 User Manual

Sign	Status	Explanation		
(GREEN) OFF		The network connection isn't normal.		
ALARM ON		Device alarm		
(RED)	OFF	No alarm		



## **3 Installation**

## 3.1 Packing List

After receiving the package of DataHub, please check whether the accessories are complete and there is no obvious damage to the appearance. If there is any damage or items missing, please contact the dealer.



## 3.2 Device Installation

#### 3.2.1 Indoor Wall Mounting

- 1) Choose a flat and solid indoor wall to drill for installation;
- 2) Hang the DataHub on the wall with the cable connection area facing down.





#### 3.2.2 Guide Rail Mounting

- 1) Use the four M3\*L6 screws in the accessory bag to fix the buckle on the DataHub.
- 2) Please prepare 35mm standard rail (effective length  $\geq$ 230mm) and install it firmly.

\*Note: The outdoor installation must be in a waterproof housing.





## **4 Cascade Connection**

## 4.1 Inverter Connection

- 1) The inverter is connected to the DataHub through the RS485 daisy chain. For the connection method of the inverter, please refer to the inverter installation manual;
- 2) It is recommended that the number of devices connected to each channel of RS485 is less than 20;
- The baud rate, communication protocol and verification method of the inverters connected to the same RS485 port of DataHub must be consistent, and the communication addresses of the inverters must be consecutive and not repeated.



4.2 Installation of RS485

Make sure that RS485+ is connected to DataHub's RS485+, RS485- is connected to DataHub's RS485-, RS485 GND is connected to the GND of DataHub.







## 4.3 Installation of DI Signal Cable

DataHub can access DI signals such as remote control and alarms through the DI port.



## 4.4 Installation of AI Signal Cable

#### Installation advice:

- > It is recommended that the transmission distance does not exceed 10 m;
- > AI port 0 and AI port 1 are connected to AI signal +, and GND is connected to AI signal-.





## 4.5 Installation of DO Signal Cable

The DO port supports 12V signal voltage in maximum. The contact of four-group output is on by default.



## 4.6 Installation of Network Cable

- > Use Cat 5e or higher specifications and Shielded crystal head connectors to prepare the network cable.
- > The communication distance does not exceed 100 m.
- When crimping the network cable, ensure that the shielding layer of the network cable is properly connected to the metal shell of the RJ45 connector.





## 4.7 Connecting to Ripple Control Receiver



## 4.8 Connecting to DRED





## **5** Configuration Function

## 5.1 Login

Hotspot login: connect the computer to the DataHub hotspot (WiFi \_xxxxxx), and use the computer to access 5.8.8.8 to enter the login interface .

WiFi login: Connect the computer and DataHub to the same WiFi, and then visit http://datahub.local/ to log in. If the user cannot access, please install the Bonjour SDK, or log in through the DataHub LAN IP address.

After entering the login interface, enter the account name and the corresponding initial password:

Administrator account: admin, initital Password: (the same as Registration Number).

User account: user, initial Password: 123456. Visitor account: visitor, initial Password: 123456.



### 5.2 Site Management

#### 5.2.1 Add Device

The devices supported by DataHub are as follows: Inverters, Electricity Meters, and Environmental Monitors. Select the device type under the serial port, set the starting address and the number of devices under the serial port, and save these settings.



Overview	RS485 Channel	Device Type	Initial Address	Number of Devices		
	1	Inverter	1 ~	1 ~		
5to Management	2	Inverter ~	0 ~	0		
Site Management	3	Inverter $\sim$	0 ~	0 ~		
Add Device	4	Meter 🗸	0 ~	0 ~		
	Check Device Detail			Save		
Site Setting						
<u> </u> ≏−∩						
احصا Inverter Setting						
Inverter Upgrade						
ന്ദ						
رین DataHub Setting						

The device details will pop up. Please confirm whether the model is correct and then Click "Save".

evice Detail				
RS485 Channel	Device ID	SN	Device Type	Device Type
1	1	unknown	Inverter	unknown 🗸
Update Device Type				Save



#### 5.2.2 Device Detail

Overview	Export						
	RS485 Channel	Device ID	SN	Device Type	Device Type	Operating Status	Version
Site Management	1	1	unknown	Inverter	unknown	unknown	0.00
Add Device							
Device Detail							
Site Setting							
Inverter Setting							
Inverter Upgrade							
DataHub Setting							

Click the corresponding device to query the device data, or select the device to export the device data.

### 5.3 Sits Setting

"Site setting" is equipped with three modules, which are "export limit control", "power control" and "meter reversion". The "export limit control" and the "power control" are mutually exclusive so that only one can be enabled.

#### 5.3.1 Export Limit Control

The purpose of the "export limit control" is to limit the power supplied to the grid. The inverter generates electricity to the grid when the power source is positive, and takes electricity away from the grid when the power source is negative. For example: The exported power is set to 0kW, the power generated by inverter is 5kW, the power load consumed is 4kW, the inverter generates 1kW(5kW-4kW = 1kW), then DataHub will limit the power generated by inverter to 4kW.

The control methods are divided into "average phase control" and "minimum phase control". If the "export power" were limited to 0kW, there will be no influence on a single-phase inverter, the inverter will not supply power to the grid. As for a three-phase inverter, the "average phase control" is to average the power of the three phases generated by the inverter. For example: the three-phase loads are 3kW, 4kW and 5kW respectively, a total of 12kW. Under the "average phase control", the power generated by the three-phase inverter is 4kW, 4kW, and 4kW respectively, a total of 12kW, as well.

Under the "minimum phase control", the power generated by the three-phase inverter is 3kW, which is the minimum power of the three-phase loads.

\*Note: Before using the "export limit control" function, make sure that a meter has been added to the DataHub. The output of device will be abnormal when connecting to three phase three wire under "minimum phase control" mode.



Overview		Export Limit Control
	Enable Disable	Enable
<u>ب</u>	Control Mode Net M	retering Mode
Site Management	* Export Power(%) 0.0	
Le	0 Feedin	/ [+] . Consumed [-]
Site Setting	Reset	Submit
Export limit Control		
Power Control		
Meter Reversion		
r <del>-</del> -1		
Inverter Setting		
с Ф		
Inverter Upgrade		
63		
DataHub Setting		

#### 5.3.2 Power Control

Power control includes "ripple control" and "DRM control" disable.

The "ripple control" is to control the active power and reactive power of the inverter according to the high or low input of the DI port. There are a total of 16 situations for users to set the active and reactive power according to each situation.

	Ripple Control Receiver DRED Control Disable								
Overview	D1 D2 D3 D4	Enable	Setting	Active Power%(0~100)	Power Factor%(80~100)	Reactive Mode			
َ کُ	0000		Please Select V	0~100	80~100	Please Select V			
Site Management	000		Please Select ~	0-100	80-100	Please Select V			
la	0000		Please Select	0~100	80~100	Please Select 🛛 🗠			
Site Setting	••00		Please Select V	0~100	80-100	Please Select V			
Export limit Control	0000		Please Select 🛛 🖂	0~100	80~100	Please Select V			
Power Control	• • • • •		Please Select V		80~100	Please Select			
Matan Baumian	$\bigcirc \bullet \bullet \bigcirc$		Please Select V	0-100	80-100	Please Select V			
	•••0		Please Select V		80~100	Please Select 🛛 🗡			
	0000		Please Select V	0-100	80~100	Please Select Y			
Inverter Setting	•00•		Please Select V	0~100	80~100	Please Select V			
æ	$\bigcirc \bullet \bigcirc \bullet$		Please Select Y	0~100	80~100	Please Select 🛛 🗠			
Inverter Upgrade	••••		Please Select	0~100	80~100	Please Select V			
<u>~</u>	$\circ \circ \bullet \bullet$		Please Select 🛛 🗠	0~100	80~100	Please Select Y			
ççy ,	• • • •		Please Select	0-100	80~100	Please Select 🗸 🗡			
DataHub Setting	$\bigcirc \bullet \bullet \bullet$		Please Select V	0~100	80~100	Please Select V			
	••••		Please Select	0-100	80-100	Please Select ×			
						Submit			
						Submit			

DRED control is applied to set the active power according to high or low input of the A1, D1, D2, D3 and D4 of DI ports.

Mode	Operate	Explanation	Note
DRM0	Close S9,S0	Inverter shutdown	
	Close S9,S1,	Close S1 charging power is 0%	When two or more DRM
DRIVIT	disconnect S0	Close 51, charging power is 07	modes work at the same
DRM5	Close S9,S5	Inverter does not output active power	time, take the optimal result
DDM6	Class 50 5(	The active power output by the inverter does	that can satisfy both of them.
DRIVIO	Close 39,30	not exceed 50% of the rated power	
	Close S9,S7	The active power output by the inverter does	
		not exceed 75% of the rated power	
		The active power of the inverter output power	
	C1 C0 C0	starts to recover.	
DKIVIO	Close 39,30	Description: The inverter outputs according to	
		the active power percentage set by DataHub.	





Overview				Ripple Control Receiver	DRED Control O Disab	le		
	Current Status	DRM Mode	A0			D2	D3	功率
ن کک		0	•	•	•	•	•	Turn Off
Site Management		1	•	•	•	•	•	Charging power0%
		5	•	•	•	•	•	power0%
<u>L</u> @		6	•	•	•	•	•	power50%
Site Setting		7	•	•	•	•	•	power75%
Export limit Control		8	•	•	•	•	•	power100%
Power Control Meter Reversion								Submit
Inverter Upgrade								
<b>ري)</b> DataHub Setting								

#### 5.3.3 Meter Reversion

When the current direction of the users meter is reversed, there is no need to rewire, just turn on the enable switch and submit this setting.

Overview	Meter Reversion
Site Management	meter-2: Disable C Enable Repet Scient
Site Setting	
Export limit Control Power Control Meter Reversion	
Inverter Setting	
Inverter Upgrade	
DataHub Setting	

## 5.4 Inverter Setting

There are three functions under "inverter setting": "inverter active/reactive power setting", "remote system switch" and "parameter setting".

#### 5.4.1 Inverter Active/Reactive Power Setting

Remotely set the active or reactive power of the inverter. The reactive power mode is divided into "overexcited",

"underexcited", "fixed reactive power" and "disable" terms. (multiple selections are available)



#### 5.4.2 Remote System Switch

Select the inverter to be controlled (Inverters can be selected in batches)



#### 5.4.3 Parameter Setting

Professionals can read and write the inverter through the inverters "modbus opcode", under which there are "READ\_HOLDING\_REGISTERS","READ\_INPUT\_REGISTERS","WRITE\_SINGLE\_REGISTER"and"WRITE \_MULTIPLE\_REGISTERS". (Can be operated in batches)

## 5.5 Inverter Upgrade

Using DataHub to upgrade the inverter. Click "Upgrade" to select the upgrade file types which include "ARM", "MDSP", "SDSP", "ARC", "ARM+DSP", "BMS\_M" and "BMS\_S". Select the corresponding file to upgrade the inverter.

\*Note: It takes nearly 15-30 minutes to upgrade the inverter. During upgrading, no data will be uploaded.



## 5.6 DataHub Setting

#### 5.6.1 Internet Setting

Network settings are divided into: "IP setting" and "WiFi setting".

IP setting: If the user needs to fix the IP, select the correct network card type, turn off the automatic acquisition of IP address, and set the "IP address", "subnet mask", "gateway" and "DNS".

WiFi setting: Provides the function of connecting to WiFi.

\*Note: Ordinary users do not need to perform any operations if they do not need a fixed IP.



5.6.2 Time Setting



The time setting is to set the DataHub system time, including "time synchronization", "SolaXCloud synchronization" and "other server synchronization".

"Time synchronization": The system corrects the time automatically.

"SolaXCloud synchronization": The platform of SolaX sends a synchronization command to change the time of system.

"Other server synchronization": The IEC104 server sends a synchronization command to change the time of system.

#### 5.6.3 Serial Port Settings

Serial port settings is to set the baud rate of the four serial ports of DataHub, the default value of the baud rate is 19200. The user can change the baud rate under the serial port according to the model.

\*Note: The baud rate of the model under the serial port is consistent, and it is consistent with the serial port baud rate set by datahub. The default value of the stop bit is 1.

	Serial Port Setting					
Overview	RS485 Channel Agreement Type		Baud Rate	Verification Method	Stop Bit	
Site Management	1	modbus	9600 ~	No Verification $\checkmark$	1 ~	
_	2	modbus 🗸	19200 ~	No Verification $\sim$	1 ~	
Lø .	3	modbus ~	19200 ~	No Verification	1 ~	
Site Setting	4	modbus	19200 ~	No Verification $\checkmark$	1	
Inverter Setting					Save	
Inverter Upgrade						
CCC DataHub Setting						
Internet Setting						
Time Setting						
Serial Port Setting						
Other Setting						
DataHub Info						

#### 5.6.4 Other Setting

The "platform setting" is the setting to upload the data to the platform, the data is sent to SolaXCloud by default, and the other is sent to the IEC104 server.

The "database storage setting" is a path for inverters to store data. There are two storage paths including the "default" and the "SD card". The "default" is to store data on the Datahub.

Electricity price setting: Calculate the income through the electricity price and display it in the overview interface.

"CO2 savings factor": Calculate the amount of CO2 through the coefficient and display it in the overview interface.

If the database storage path is a TF card, the TF card cannot be pulled out when the system is running. If you want to pull out the TF card, you need to change the storage path to the default, and then pull out the TF card. (It is recommended to unplug after power off)

<sup>\*</sup>Note :

It is recommended to use a TF card with a capacity of 16G;



	Overview	Cloud Platform Setting				
	^	Data Uplaad Platform SolaXCloud				
Site Management	٤	Local Address				
	Site Management	Platform Server Address				
<u>_</u> @	Lø 🗸	Platform Server Port				
	Site Setting	Read Dadwe				
	المحت Inverter Setting	Database Storage Settings				
	$\sim$	Database Storage Path Detault 🕓				
C12 Inverter Upgrade	Reset Submit					
	¢¢	Electricity Price Setting				
	DataHub Setting	Electricity Price Setting(Per kWh) 0.00				
	Internet Setting	Rest Cont				
	Time Setting					
	Serial Port Setting	CO2 Savings Factor				
	Other Setting	CO2 Savings Factor 0.997				
	DataHub Info	Read				
	DataHub Upgrade					

#### 5.6.5 Datahub Information

"Datahub information" displays the basic information of datahub, including "registration number", "firmware version", "internal codes", "system time", "memory usage", "free disk time", "free SD space", "Wi-Fi connection", "lan IP address", and "WiFi IP address".

Clear historical data: Clear the historical data of the device.

Overview	DataHub Info				
~	SN				
ن ک	Firmware Version	3.09			
Site Management	Internal Codes	V002.02			
Lø 🗸	System Time	2022-04-27 19:21:40			
Site Setting	Memory Usage	20.0%			
Ē	Free Disk Space	4.9G			
Inverter Setting	Free TF Space	NA			
Ô	WI-FI Connection	unknown			
Inverter Upgrade	LAN IP Address	10.1.1.57			
<u>~</u>	WIFI IP Address	wlan0: error fetching interface information: Device not found			
DataHub Setting		Clearing Historical Data			
Internet Setting					
Time Setting					
Serial Port Setting					
Other Setting					
DataHub Upgrade					

#### 5.6.6 DataHub Upgrade

Click the "click to upload and upgrade" button to upload and upgrade the DataHub, then select the upgrade file and wait for the upgrading. (Only one file can be uploaded at a time, and the interface needs to be refreshed for continuous operation.)

## 5.7 Password Modification

The system provides two methods for modification: "modify Password" and "reset user Password".



DataHub 1000 User Manual

					an Medity Decouved	dmin ~ @ Select Lang	uage ∽ ( <sup>U</sup> Log
Overview	(b) - b) 24	total	$\mathbf{\circ}$	Device Info	User Password Manager	nent	
Site Management	Daily Yield 0.00 kWh	Total Yield 0.00 kWh	Output Power System Size 0.00 kW	RS485 Channel Device Type 1 Inverter	Total Devices Online	1 Offline	Status
Site Setting	CO2 Reduction	Income&Saved	grid Grid Power				
Inverter Setting	0.00 kg	0	0.00 kW				
	Nonthly Yield	Daily Yield		Daily Power Curve	-O- Total Output Power -O- Grid I	Power	
DataHub Setting				0.8			

## 5.8 System Resetting

System resetting restores the system to factory settings, the historical data and the configuration information of datahub will be cleared.

Operation: press and hold the "recover" button for 10 seconds until all three LEDs are off, and then release it. After completing the above operations, the service restarts and the system reset is complete.



## 6 Technical Specifications

Product	DataHub1000		
hardware			
Power adapter	100-240V 50/60HZ AC Input 12V 2A DC Input		
Rated power	24W		
Data transfer interval	5min		
Storage capacity	8G/16G TFcard		
The number of managed devices	60		
communication			
Inverter communication	3xRS485		
wireless module	WiFi 2.4GHz		
access network	WiFi		
Communication of electricity			
meters and environmental	1xRS485		
detectors			
Communication distance	wireless >15m, WiFi > 500m		
DRM interface	Australia only		
USB interface	1 USB Interface (For local upgrade and parameter setting)		
Dry Node Control Receiver	2AI,4DI,4DO (Reserved for external expansion)		
General parameters			
Dimensions (length*width*height)	205*124*33		
Weight	<=500 g		
Operating Temperature Range	$-20^{\circ}\mathrm{C} \sim +60^{\circ}\mathrm{C}$		
Degree of Protection	IP21		
Installation method	Wall-mounted, rail-mounted		
Indicator light	LED		
standard			
Certification	RED/FCC/CE/RoHS		



## 7 Certified Quality Assurance

## 7.1 Certification mark

# 

## 7.2 Warranty

SolaX grants a standard 24-month warranty, if it is otherwise stipulated in the contract, the contract shall prevail.

## 7.3 Warranty Conditions

In case the product is operated according to the above instruction, SolaX will provide after-sales service during the product warranty period if any failure (error) is caused by product quality.

## 7.4 Exclusion of Liability

Warranty claims are excluded for direct or indirect damage due to:

- 1) Warranty period for the product or accessories have expired, but not extended;
- 2) Failure to operate the product in accordance with the installation and maintenance requirements described in the relevant manual;
- 3) Failure or damage caused by not operating, storing and using in the specified working environment;
- 4) Failures or damages caused by unforeseen unexpected factors, human factors or force majeure; and
- 5) Other failures or damages not caused by DataHubs own quality problems.



## 8 Contact Us

If you have any question or any technical question about DataHub, please contact us through the following methods, we will serve you wholeheartedly.

SolaX Power Network Technology (Zhejiang) Co., Ltd. ADD: No.288 shizhu Road, Tonglu Economic Zone, Tonglu City, Zhejiang Province, China. Tel: +86 571 56260011 FAX: +86 571 56075753 EMAIL: service@solaxpower.com WEB: www.solaxpower.com