





- 1. Fuses for Indication Lights
- 2. Grid Indication Light
- 3. Main MCB 63A
- 4. Over & Under Voltage Protection
- 5. Inverter Input MCB 63A
- 6. Grid Surge Protection Device Type B+C
- 7. Inverter Output MCB 50A
- 8. Inverter Output Surge Protection Device
- 9. Change Over Switch 63A
- 10. Inverter Output Indication Light



INGE FZE



Wiring Diagram

This DB is wired with 10mm GP wire